

INSTALLATION GUIDELINES

ECCO 2Connect

Weed-free joint filler for heavy traffic loads
epoxy-based



1. Preparation

Clean the pavement and joints to ensure all weeds and dirt are removed.



2. Mixing components with sand and water

Mix components A and B well with the quartz sand for 3 minutes. Afterwards, add up to 3 litres of water to the mixture and mix again for 3 minutes.



3. Applying joint filler to paving

Pour the ECCO 2Connect joint filler onto the paving that has been moistened beforehand. Sweep the joint filling into the joints with a hard broom or rubber squeegee. (*)



4. Sweeping until desired result

After 10 to 30 minutes, sweep with a soft broom until the desired result is achieved.



(*) We recommend testing out the joint filler on a small area in advance.

ECCO  **PRODUCTS**