



ECCOBORDER FLEX

ECCO PRODUCTS



Quick & easy installation

01

Preparation

Dig a trench following the chosen installation shape. ECCOborder Flex is a border on roll that is ideally suited for curved shapes, but can definitely also be used for straight sections if an anchor is placed every 80 to 100 cm.



02

Placement

Place the ECCOborder Flex at least 2/3 into the ground, in the trench that has been provided for that purpose. You can install the ECCOborder Flex with a flat or rounded top edge, depending on your choice.



03

Anchoring

Hammer the Multi Profile fixing posts into the ground using a rubber or wooden mallet. The Multi Profile anchoring ensures increased stability. The top of the posts should be about 3 cm lower than the top edge of the ECCOborder Flex.



04

Mounting

Depending on the application, we recommend anchoring every 80 to 100 cm. ADVICE: Attach the ECCOborder Flex to the Multi Profile posts with self-drilling countersunk screws, length 45 mm.



05

Finish

Complete both sides of the border with soil, bark or gravel according to the chosen application.

