




INSTALLATION WITH GRASS

MULTIDAL



Frost-resistant gravel/grass grid in HDPE with high pressure resistance

01

Excavation

Perform the necessary excavation works. Always remove the topsoil to load-bearing soil. The load-bearing capacity of this layer should be at least 20 Mpa.

02

Borders

Install the borders. They should be 2 cm above the level of the top of the grid.

Only for cars

Foundation layer

Create a foundation layer at least 25 cm deep. Use a foundation substrate, which provides both a stable base and nutrients. Afterward, apply weight to the compacted foundation (e.g. with a heavy roller).

03

Bedding layer

Lay the bedding layer using bedding substrate. For vehicle applications, the bedding layer should be 5 cm deep. For non-vehicle applications this depth should be 15 cm.

04



Multidal

- a. Position the first Multidal parallel to the demarcation.
- b. With the new click system, you easily connect the next grid. If you need to, you can also disconnect it.
- c. We recommend to install the grids in half-brick bond. Start the second row with half a slab, the Multidal is easy to cut with a grinding wheel.
- d. Start the third row again with a full grid. Finish the entire surface in this way so the installation is half-brick.

Substrate

Fill the grass grids with substrate up to 1 cm (max. 0.5 cm) below the edge of the grid. Use grass grid substrate and brush thoroughly to distribute it evenly and avoid gaps.

Tip: Never fill the grass grids with only topsoil. Topsoil can compact too much, preventing grass seed from germinating.

Sowing & waiting period

- » Sow the grass into the Multidal.
- » After 6 to 8 weeks, you can start using the grass parking. If the parking area will be heavily used, we recommend waiting 16 weeks to allow the grass to grow densely.



05

06

07